

Микрофоны измерительные DELTA OHM MC21E

Технические характеристики

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Казахстан (772)734-952-31

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Таджикистан (992)427-82-92-69

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: dmh@nt-rt.ru || www.deltaohm.nt-rt.ru

MC21E MICROPHONE (FREE FIELD)

MC21E is a condenser type microphone, pre-polarized (0V) with standard ½ "diameter. The frequency response, optimized for free field, is flat from 3.2 Hz to 20 kHz.



Applications

- Acoustic measurements with frontal source
- Class 1 precision sound pressure level measurements
- Optimized free field response
- Outdoor Measurements (with HDWME outdoor protection)

Free field microphones are used to measure the existing sound pressure before the microphone is inserted into the acoustic field. The body of the microphone in fact, with its shape and its dimensions, influences the sound field, due to reflection and diffraction phenomena, mainly at high frequencies, where the wavelength of the sound is comparable to the dimensions of the microphone capsule. This phenomenon is physically manifested (disturbance of the acoustic field) with an increase of sound pressure mainly at high frequencies (above 1kHz). The microphones are then compensated to linearize the response in order to obtain a linear free field frequency response curve.

TAB 1

Model	MC21E
Technical Specifications	
Nominal diameter	½"
Precision class	1
Acoustic Response	Free Field
Frequency range	3.15Hz ÷ 20KHz (±2dB)
Polarization (V)	0
Sensitivity (dB re. 1V/Pa)	-26
Nominal sensitivity (mV/Pa)	50
Temperature range	-40 ÷ +120 °C
Temperature coefficient	- 0.009 dB/°C
Pressure coefficient	-1.3x10 ⁻⁵ dB/Pa
Capacity (pF)	12
Max level (dB)	146
Intrinsic noise (A weighted)	15
Membrane material	Nickel
Dimensions (mm)	13.2 (diam) x 16.4

MICROPHONE DRIFTS

Microphone drift coefficient	Value	Maximum Drift [dB]
Ct – temperature	-0.009dB/°C	± 0.3
Cp – static pressure	-0.013dB/kPa	± 0.2
Cu – relative humidity	-	± 0.3

Drift coefficients of acoustic sensitivity, due to temperature and static pressure, generating the sensitivity of microphone-preamplifier-instrument chain to drift (within the limits specified for class 1 according to IEC

Архангельск (8182)63-90-72	Ижевск (3412)26-03-58	Магнитогорск (3519)55-03-13	Пермь (342)205-81-47	Сургут (3462)77-98-35
Астана (7172)727-132	Иркутск (395)279-98-46	Москва (495)268-04-70	Ростов-на-Дону (863)308-18-15	Тверь (4822)63-31-35
Астрахань (8512)99-46-04	Казань (843)206-01-48	Мурманск (8152)59-64-93	Рязань (4912)46-61-64	Томск (3822)98-41-53
Барнаул (3852)73-04-60	Калининград (4012)72-03-81	Набережные Челны (8552)20-53-41	Самара (846)206-03-16	Тула (4872)74-02-29
Белгород (4722)40-23-64	Калуга (4842)92-23-67	Нижний Новгород (831)429-08-12	Санкт-Петербург (812)309-46-40	Тюмень (3452)66-21-18
Брянск (4832)59-03-52	Кемерово (3842)65-04-62	Новокузнецк (3843)20-46-81	Саратов (845)249-38-78	Ульяновск (8422)24-23-59
Владивосток (423)249-28-31	Киров (8332)68-02-04	Новосибирск (383)227-86-73	Севастополь (8692)22-31-93	Уфа (347)229-48-12
Волгоград (844)278-03-48	Краснодар (861)203-40-90	Омск (3812)21-46-40	Симферополь (3652)67-13-56	Хабаровск (4212)92-98-04
Вологда (8172)26-41-59	Красноярск (391)204-63-61	Орел (4862)44-53-42	Смоленск (4812)29-41-54	Челябинск (351)202-03-61
Воронеж (473)204-51-73	Курск (4712)77-13-04	Оренбург (3532)37-68-04	Сочи (862)225-72-31	Череповец (8202)49-02-64
Екатеринбург (343)384-55-89	Липецк (4742)52-20-81	Пенза (8412)22-31-16	Ставрополь (8652)20-65-13	Ярославль (4852)69-52-93
Иваново (4932)77-34-06	Киргизия (996)312-96-26-47	Казахстан (772)734-952-31	Таджикистан (992)427-82-92-69	

Единый адрес для всех регионов: dmh@nt-rt.ru || www.deltaohm.nt-rt.ru